

# FG-OD Accessories

# Connection Accessories & Kits

**Product Datasheet** 



# **Description**

TTK oil leak detection systems offer a full range of connection accessories and kits as diversion boxes, leading cables, end termination to use with FG-OD sense cables and different alarm units. These items assure a proper functioning of the systems.

For all other connection accessories and kits refer to the Accessories datasheet.

#### Boxes

The components used for the following boxes having features as below:

- ABS POLYAC 707 (a natural ABS)
- Rated UL94 HB; Halogen Free
- IP67
- Dimensions (L x W x H): 105 x 75 x 55mm

#### Item FG-DOD



#### **Description**

FG-DOD is an OD Bus Interface Box.

It is used for FG-OD sense cables installed in combination with a water/acid installation on FG-NET digital units.

 $\ensuremath{\mathsf{Up}}$  to ten FG-OD sense cables can be connected to one FG-DOD.

The LED on the front face of the box indicates the box's status in real time:

• Short blue followed by a long green blinking

- LED: normal, no alarm.

  Short blue followed by a long red blinking LED:
- leak alarm on the OD bus.

  Short blue blinking LED only: detected on the
- Short blue blinking LED only: detected on the box.
- No LED (off): loss of communication.

## Compatibility & Connectivity

Digital unit: FG-NET, FG-BBOX




#### FG-DOP



FG-DOP is a point sensor diversion. It is a connection box for integration of FG-ODP on a OD BUS

Digital unit: FG-NET, FG-NET-LL, FG-BBOX, FG-BBOX-LL, FG-ALS8-OD, FG-ALS4-OD

Box: FG-DOD Point Sensor: FG-ODP



#### **FG-DOD** Kit



The FG-DOD Kit includes: one interface box FG-DOD + one leader cable FG-CLOD + one end termination FG-TMOD.

Digital unit: FG-NET, FG-BBOX

# Leading Cable & Kit

# FG-CLOD Leader cable in 3.5m to connect the first OD sense cable to the digital unit FG-NET-LL or FG-BBOX-LL, FG-ALS8-OD, FG-ALS4-OD.

#### FG-NOD15 / FG-NOD7 / FG-NOD3

TTK 8771' jumper cable  $15\,\mathrm{m}$  /  $7\,\mathrm{m}$  /  $3\,\mathrm{m}$  with connectors.



#### **FG-NOD Kit**



Set of parts for connecting FG-OD jumper cable. It includes male, female connectors with cable + contacts + adhesive + heat shrinkable sleeve.

A connection notice with photos is included.

# **End Termination**


Item	Description
FG-TMOD	End termination plug.
	Each circuit of sense cable must be ended with an end termination plug; FG-TMOD is used for the FG-OD circuit continuity.

### Accessories for Installation

#### Item

#### **Description**

#### FG-FLOAT2



FG-FLOAT2 is a float assembly designed to be used with FG-ODP, the point sensor for oil leak detection - in sump application and other similar applications, to detect oil floating on water. For more information, refer to «FG-FLOAT2» datasheet.

#### CF-OD50



Set of 50 hold-down clips with glue dedicated for oil sense cables. It is recommanded to install the clips at intervals of no greater than 1.5 m and at every change of direction.

#### ES-OD



Set of 40 tags.

Labels ES-OD indicate the presence of oil sense cables installed. It is recommended to fix the labels every five meters on the circuit of sense cables and ensure a good visibility of the labels.

#### OD-ADAPT - V1/V2



This v1 to v2 adaptor allows to interconnect the version 1 connector to the version 2 connector of FG-OD sense cables: plug in v1, socket in v2.

#### OD-ADAPT - V2/V1



This v2 to v1 adaptor allows to interconnect the version 2 connector to the version 1 connector of FG-OD sense cables: plug in v2, socket in v1.

#### **UVBRAID**



This wrap-around sleeve protects outdoor installed hydrocarbon sense cables exposed to sunrays from UV rays.

This brochure has been carefully prepared to ensure technical accuracy but is only intended for promotional use. TTK cannot guarantee that the information contained herein contains no errors or omissions, and hence does not accept responsibility related to the use of its equipment. TTK maintain its obligations set forth in the Standard Terms and Conditions of Sale and will not, under any circumstances, assume liability for any incidental damages, indirect or consequential, arising from the sale, resale, use or misuse of this product. The purchaser(s) accept their responsibility as the sole judge(s) of the adaptability of the product for the intended use.

FG-NET, FG-SYS and TOPSurveillance are trademarks of TTK S.A.S. © TTK 2020

- TTK Headquarters / 19 rue du Général Foy / 75008 Paris / France / T:+33.1.56.76.90.10 / F:+33.1.55.90.62.15 / www.ttk.fr / ventes@ttk.fr
- TTK Oil & Gas Division / 19 rue du Général Foy / 75008 Paris / France / T:+33.1.56.76.90.10 / F:+33.1.55.90.62.15 / www.ttk.fr / rrisi@ttk.fr
- TTK UK Ltd. / 3 Luke Street / London EC2A 4PX / United Kingdom / T:0207 729 6002 / F:0207 729 6003 / www.ttkuk.com / sales@ttkuk.com
- TTK Pte Ltd. / #09-05, Shenton House, 3 Shenton Way / Singapore 068805 / Tel.+65-6220.2068 / Mob: +65.9271.6191 / Fax. +65-6220.2026 / www.ttk.sg / sales@ttk.sg
- TTK Asia Ltd. / 2107-2108 Kai Tak Commercial Building / 317 Des Voeux Road Central / Hongkong / Tel.+852.2858.7128 / Fax.+852.2858.8428 / www.ttkasia.com / info@ttkasia.com
- TTK Middle East FZC0 / Building 6EA, Office 510 PO Box 54925 / Dubai Airport Free Zone / UAE T: +971 470 17 553 / M: +971 50 259 66 29 / www.ttkuk.com / cgalmiche@ttk.fr
- TTK Deutschland GmbH / Berner Strasse 34 / 60437 Frankfurt / Deutschland / T:+49(0)69-95005630 / F:+49(0)69-95005640 / www.ttk-gmbh.de / vertrieb@ttk-gmbh.de | TTK North America Inc / 1730 St. Laurent Boulevard, Suite 800 / Ottawa, ON K1G 5L1 / Canada / T:+1 613 566 5968 / www.ttkcanada.com / info@ttkcanada.com
- Thomas Sales & Marketing Inc. TTK Master Distributor For USA / 7200 W 66th St / Bedford Park, IL 60638 / The United States /T: +1 630-518-4724 / www.ttkusa.com / dmolk@ttkusa.com